

# 8 speaker system

The Dome setup has an audio setup containing 8 speakers, 1 amplifier, 1 sound interface.

On the MAIN Dome computer the sound interface software can be used to control the audio system. A configuration template is available File > load > snapshot ...

The Sub speaker is located at monitor output 1. You can find this speaker behind the Dome in the corridor next to Texspace. Turn it on manually, remember to turn it off when finished working ;)

To play audio through this system make sure your audio file is configured the right way. Depending if you want to play audio over 2 or 8 channels. Also if you play your video and audio from the 1st computer make sure the usb cable from the sound interface is plugged in that computer and use the sound interface software on that computer.

---

Revision #2

Created 2023-09-25 13:45:19 UTC by Simone

Updated 2024-12-05 13:00:34 UTC by Simone