Light Consoles

There is a wide variety of consoles in the world. In this chapter we only mention the ones that we at HKU have some experience with.

- ColorSourceAV 20

ColorSourceAV 20

Fader Mode; Bumps; Crossfader - ETC ColorSource 20 User M

Image not found or type unknown

Information about the device

Website

Manual



de on the touchscreen.

ETC 20-Fader ColorSource AV Console with Network, Audio, and | Reverb

Image not found or type unknown

Use the faders to turn on lights that are programmed under the channels that correspond with the faders.

Use the buttons under the faders to select the fixtures for changing color.
Change color by choosing the color droplet on the touchscreen (bottom area) to open the color tab.
You can change the view of the color picker window by choosing the color tab several times.
If you want to choose colors in warm or cold range whites then choose the "whites" button next to the color picker view.





Cuelist

A cue is a recorded stage look that can include channel settings for intensity and other parameters, effects, and media

Interface start position:
Select Channel mode (left display)
Cuelist
Move Cues slider up (sliders above display, 3rd slider)
Controls > cue list



Explanation cues (scene) list:
The top line is the previous scene,

2nd line is the current scene
3rd line is the next scene



Interface operation:
Play button to advance through cues
More > gotoO = go to start scene (black)
More > goto cue (3) = go to scene 3

More > flag, give current cue a flag so you recognize it as important
Record Edit > Cue list = delete, adjust, copy, etc. from the list or individual cues.

Record cues
Make a picture: turn on lights and choose colors
Record/edit > record > cue > name (press the input box above "name" on the touchscreen)

Adjust time by pressing the input boxes and adjusting time.
Store
Clear>all
Move all light buttons down
Create new image etc...

Adjust cues:
record/edit > cue list > select cue (cue fader down) > edit cue (cue fader up) > select lamp by pressing buttun under fader of the lamp > adjust color (controls > color > choose color) > Store or store & next and choose check mark (green button on the left bottom of screen) > Exit