

Using BrightSign as a super simple player for HD video

Brightsign

- Record your video
 - edit it if necessary, export as Mp4 Full HD resolution
- **Format/Clear** the micro SD card, don't forget to EMPTY YOUR BIN
- Copy the video file(s) to the microSD card
- Enter the MicroSD in the BrightSignPlayer
- Connect the player to a projector/screen (HDMI) and power.
- Have patients, the BrightSign will eventually start! (approximately 1 minute)
- Press the SVC button to speed up this proces.
- Your video will now play in loop.
- To stop this, unplug the BrightSign

Check out the other bookstack pages on these players if you want to use advanced options.

Notes;

Ls4 can play HD & 4K video, but the monitor also need to be capable of showing this resolution. 4k = blackscreen on a lower resolution monitor.

Ls5 can play HD & 4K video, and downscales the 4k to something the monitor is capable of showing.

More info on compatible codecs & resolutions [here](#) or check the datasheet for the [LS4](#) or [LS5](#)

Revision #6

Created 26 March 2024 08:43:34 by Astrid

Updated 8 January 2025 19:04:15 by Job